



# TEMPTEST® BLUE

Bluetooth® thermometer



- Clean probe and housing with anti-bacterial wipe after each use.
- Don't pry, jab, or force probe tip into food.
- Don't puncture containers or lift food with probe.
- Don't drop or rest on surfaces above 50 °C (122 °F).
- Don't attempt to reshape battery contacts.
- Don't overtighten battery cover screw.

For technical assistance, please contact our technical sales office on 01903 202151 or email [technical@etiltd.co.uk](mailto:technical@etiltd.co.uk)

**ELECTRONIC TEMPERATURE INSTRUMENTS LTD**

Worthing · West Sussex · BN14 8HQ

01903 202151 · [sales@etiltd.com](mailto:sales@etiltd.com) · [etiltd.com](http://etiltd.com)